
## LIGHTHEAD Manual

## Surface Mount

- 1. Decide mounting location. ©=
- 2. Use mounting foam pad as guideline and drill holes.
- 3. Secure lighthead with supplied screws.



## **OPERATIONS**

To +VDC (fuse @ 2A).....

RED

For Simultaneus or Alternating Flash......WHITE

Group1 Heads: (Wiring-WHITE connected to RED) will flash together Group2 Heads: (Wiring-WHITE not connected to RED) will flash together

\*Group1 Heads will alternate with Group2 Heads\*

For Synchronization & Flash Patterns.....YELLOW \_

Connect YELLOW wires of all heads together for synchronization

\*All heads must be set at the same pattern

## Momentarily apply + VDC to YELLOW wire:

- · once for next pattern
- · quickly three times for FP#1

Note: This unit may not be factory set at pattern 1.

FP#	Flash Patterns		
1	Single (2Hz)	9	Double
2	Double (R65)	10	Triple
3	Triple (2Hz)	11	Quad
4	Quad (2Hz)	12	Quint
5	Random	13	8 Flash
6	Steady	14	Single-Quad
7	Single	15	Single H/L
8	Mega	16	Single-Triple-Quint