



The left diagram shows a circuit with a 31-pin connector. A line labeled 'HDK 7000' connects to a speaker symbol labeled 'Horn/ Fanfare'. The output is labeled 'A3' and 'A4'. The 31-pin connector is labeled '31'.

The right diagram shows a circuit with a 31-pin connector. A line labeled 'HDK 7000' connects to a transformer symbol. The transformer has pins labeled '86', '85', '30', and '87'. The output is labeled 'A3' and 'A4'. The 31-pin connector is labeled '31'.

19